

eSense Compatibility Information

Last Update May 2018



iOS devices compatible with eSense

- Apple[®] iPhone[®] 4S or higher
- Apple[®] iPad[®] (from 2nd generation)
- Apple[®] iPad[®] Pro
- Apple[®] iPod touch[®] 5th generation or higher
- Apple[®] iPhone[®] 7, iPhone[®] 7 Plus, iPhone[®] 8, iPhone[®] 8 Plus and iPhone[®] X (in combination with the included Lightning to 3.5 mm Headphone Jack Adapter)

Important notice for iOS 7 or higher: The eSense works through the microphone port. In iOS you have to allow explicitly that the eSense app may use the microphone port, otherwise it will not work. You are asked for this during installation, please answer with “Yes” or “Allow”. After installation you can make this setting manually: Allow the eSense app to use the microphone port in the system settings of your iOS device: Settings ->Privacy -->Microphone

Android devices compatible with eSense

- Android smartphones and tablets with Android 4.4 or higher, exceptions see below.

Important notice on Android devices:

- **Your Android device needs a 3.5 mm input for external microphones/headsets.** Most devices have this input, often included in the headphone jack. **If no 3.5 mm input for external microphones is present, such as with the Google Nexus 7, you cannot use eSense.** (All iOS devices specified above have this input.)

- **Some old Android devices which have a microphone jack will only work with eSense with a small adapter cable.** This cable inverts the pin assignment of the 3.5mm microphone input. **Each eSense is delivered with this adapter cable.** If you find that your eSense does not work with your Android device, please use the adapter!



Here are some **Android devices** we tested and can confirm that **they work well** with the eSense (**Whitelist**). This list is only a **very small sample** and **most available devices worldwide work fine with the eSense**.

- [Amazon Fire 7](#) (Tablet) **our recommendation for starters**
- Amazon Fire 10 HD (Tablet)
- Samsung Galaxy Note 2 (Smartphone)
- Samsung Galaxy Note 3 (Smartphone)
- Samsung Galaxy Note Edge (Smartphone)
- Samsung Galaxy S2 (Smartphone)
- Samsung Galaxy S4 (Smartphone)
- Samsung Galaxy S6 Edge (Smartphone)
- Samsung Galaxy S7 (Smartphone)
- Samsung Galaxy S8 and S8+ (Smartphone)
- Samsung Galaxy Tab A 10.1 (Tablet)
- Samsung Galaxy Tab S2 (Tablet)
- LG Optimus E610 (Smartphone)
- Huawei Ascend Y201 Pro (Smartphone)
- Huawei P8 Lite (Smartphone)
- Huawei P8 (Smartphone)

- Huawei Honor Holly U19 (Smartphone)
- Ubro M1 (Smartphone)
- TAKEE 1 (Smartphone)
- DOOGEE X5 (Smartphone)
- CUBOT H1 (Smartphone)
- Lenovo A399 (Smartphone)
- Acer Iconia A510 (10`` Tablet)
- Acer Iconia A1-810 (7`` Tablet), very cheap!

The following Android devices will NOT work with the eSense (Blacklist). There may be a few other devices not on this list which will not work. When in doubt, please check the Microphone jack as described above!

- Google Nexus 7
- Amazon Fire 8 HD

eSense Informationen zur Kompatibilität



Stand Mai 2018

iOS-Geräte die mit Sense kompatibel sind

- Apple® iPhone® (4S oder neuer)
- Apple® iPad® (2. Generation oder neuer)
- Apple® iPad® Pro
- Apple® iPod touch® (5. Generation oder neuer)
- Apple® iPhone® 7, iPhone® 7 Plus, iPhone® 8, iPhone® 8 Plus und iPhone® X (in Kombination mit dem inkludierten Lightning auf 3,5 mm-Kopfhöreranschluss Adapter)

Wichtiger Hinweis für iOS 7 und höher: Der eSense funktioniert über den Mikrofoneingang. Ab iOS 7 müssen Sie explizit erlauben, dass die eSense App den Mikrofoneingang nutzen darf, sonst kann der eSense nicht funktionieren. Bei der Installation werden Sie danach gefragt, Sie müssen dort mit „Ja“ bzw. „Erlauben“ antworten. Nach der Installation können Sie diese Einstellung manuell vornehmen. Erlauben Sie den Zugriff auf den Mikrofoneingang in den System-Einstellungen Ihres iOS Gerätes unter Datenschutz->Mikrofon

Android-Geräte die mit Sense kompatibel sind

- Allgemein Android-Smartphones und Tablets mit Android 4.4 oder neuer. Ausnahmen siehe unten!

Wichtig zur Benutzung mit Android-Geräten:

- **Ihr Android-Gerät benötigt eine 3.5 mm-Anschluss (Standard-Kopfhörer) für externe Headsets/Mikrofone.** Bei den meisten Geräten ist diese vorhanden und oft integriert mit der Kopfhörer-Buchse. **Wenn kein solcher Mikrofoneingang vorhanden ist, wie z.B. beim Google Nexus 7, können Sie eSense nicht verwenden!** (Alle oben aufgeführten iOS-Geräte haben den Anschluss.)

- **Manche alten Android-Geräte funktionieren nur mit einem einfachen Adapter-Kabel.** Das Kabel vertauscht die Anschlussbelegung der 3.5mm-Buchse. **Jedem eSense liegt ein solcher Adapter bei!** Wenn Ihr eSense an Ihrem Android-Gerät nicht funktionieren sollte, verwenden Sie bitte das Adapter-Kabel!



Im Folgenden finden Sie **einige Android Geräte**, die wir mit dem eSense **getestet** haben und welche **einwandfrei funktionieren (Whitelist)**. Bitte beachten Sie, dass dies nur ein sehr kleiner Ausschnitt ist und das die allermeisten Geräte weltweit mit dem eSense funktionieren.

- [Amazon Fire 7](#) (Tablet) **unsere Einstiegs-Empfehlung**
- Amazon Fire 10 HD (Tablet)
- Samsung Galaxy Note 2 (Smartphone)
- Samsung Galaxy Note 3 (Smartphone)
- Samsung Galaxy Note Edge (Smartphone)
- Samsung Galaxy S2 (Smartphone)
- Samsung Galaxy S4 (Smartphone)
- Samsung Galaxy S6 Edge (Smartphone)
- Samsung Galaxy S7 (Smartphone)
- Samsung Galaxy S8 und S8+ (Smartphone)
- Samsung Galaxy Tab S2 (Tablet)
- Samsung Galaxy Tab A 10.1 (Tablet, Bestseller in Deutschland)
- LG Optimus E610 (Smartphone)
- Huawei Ascend Y201 Pro (Smartphone)
- Huawei P8 Lite (Smartphone)

- Huawei P8 (Smartphone)
- Huawei Honor Holly U19 (Smartphone)
- Ubro M1 (Smartphone)
- TAKEE 1 (Smartphone)
- DOOGEE X5 (Smartphone)
- CUBOT H1 (Smartphone)
- Lenovo A399 (Smartphone)
- Acer Iconia A510 (10`` Tablet)
- Acer Iconia A1-810 (7`` Tablet), besonders günstig!

Die folgenden Android Geräte sind NICHT mit eSense kompatibel (Blacklist). Diese Liste ist nicht notwendigerweise vollständig. Wenn Sie sich nicht sicher sind, ob Ihr Gerät kompatibel ist, prüfen Sie ob der Mikrofoneingang wie oben beschrieben vorhanden ist!

- Google Nexus 7
- Amazon Fire 8 HD